

Oil-Less Rotary Scroll Air Compressors (15-20 HP)

Ohio Medical oil-less scroll compressors provide a source of clean air for medical, lab, and industrial applications. Low pressure models are capable of pressures up to 115 psi. High pressure versions provide pressures up to 145 psi. Both types are available as 15 HP or 20 HP models; their vertical design helps to save floor space in tight quarters.

Each module includes two scroll air ends belt driven by a common motor. Included are an inlet filter, belt guard, aftercoolers, relief valves, and temperature switches. They are available as stand-alone modules for field replacements; the modules can also be multiplexed in complete hospital, lab, and industrial systems.



Part #	100-0268	100-0269	100-0268-HP	100-0269-HP
Model	LOW PRESSURE	LOW PRESSURE	HIGH PRESSURE	HIGH PRESSURE
HP	15 HP	20 HP	15 HP	20 HP
CFM @ 50 PSI	55.4	68.6		
CFM @ 100 PSI	54.8	67.6	38	58
CFM @ 145 PSI			33.6	54
RPM	2500	2900	1900	2500
Inlet	1 1/2"	1 1/2"	1 1/2"	1 1/2"
Discharge	3/4"	3/4"	3/4"	3/4"
Weight	710 lb.	750 lb.	710 lb.	750 lb.